


D-type150

"Hidden hanger-type decorative gutters" which set off the eaves of large buildings beautifully.



As dressing for the eaves, the large decorative gutter "D-type 150" can accommodate all your needs.

The large decorative gutter "D-type 150" revolutionizes the image of gutters used on ordinary houses and large buildings including not only factories, warehouses, stores, and apartment buildings but also cultural facilities such as schools and art galleries. It is a completely new large decorative gutter developed with the concept of functionality and decorative quality as "dressing for the eaves", to complement the design and image of the building.





[Construction example]

Characteristics

Employs the industry's first hidden hanger system giving a sense of unity to large buildings.

The industry's first large decorative gutter to employ a hidden hanger system. Because the brackets cannot be seen, the eaves trough merges beautifully with the roof and facade, simplifying the look of the eaves and giving a sense of unity.

2 Excellent rainwater drainage and improved strength using a rib structure.

Strength is improved through the use of a rib structure at the front of the eaves trough. This makes "D-type 150" suitable not only for houses, which are increasing in size, but also for large buildings such as factories and warehouses.

An extensive range of brackets that accommodates the diverse requirements of large buildings has been put together to improve the ease of construction.

The carefully-calculated installation procedure improves ease of construction on site. "D-type 150" is easy to install and its structure provides extra strength. Due to the extensive range of brackets, the ease of construction of "D-type 150" is excellent and can accommodate the diverse requirements of any large building.

A color range that harmonizes beautifully with the building.

Five adaptable colors that bring out the beauty in all kinds of building. Reddish Brown, Grey, Black, Snow White, European White. Select the color to suit the building's image.

From large buildings such as factories, warehouses, public buildings, and apartment buildings, to ordinary houses.

"D-type 150" has revolutionized the image of gutters for large buildings.


This large "hidden hanger-type decorative gutter" is based on a new concept of following beautiful, distinctive architectural design with strength and flexibility.

Basic combinations that follow the building's image

The eaves trough gives a sense of unity, the drain specification provides harmony, and the funnel specification accentuates the gutter. All can be combined with either square or round downspouts.










Combination

Color range




Basic combination




Standard assembly diagram


D-type150




D-type150 Standard dimensions


Eaves trough series/Eaves trough brackets













































D-type150 Standard dimensions

Round downspout series






Variable elbow											
Standard	Product number	Color	No. of packages								
60F	A12L773	H·SB·W·SW·K	20								
75F	A12L775	H·SB·W·SW·K	20								

Reducing pipe												
Standard	Product number	Color	No. of packages									
60×60-60	A12Y20	H·SB·W·SW·K	20									
75×60-75	A12Y25	H·SB·W·SW·K	20									
75×75-75	A12Y30	H·SB·W·SW·K	20									

T-connector			
Standard	Product number	Color	No. of packages
60F	A13B243	H·SB·W·SW·K	100
75F	A13B20	H·SB·W·SW·K	100

Elbow for drainpipe that runs across surface of roof											
Standard	Product number	Color	No. of packages								
60×55-L110	A12L110	H·SB·W·SW·K	20								
60×55-L200	A12L805	H·SB·W·SW·K	20								

Downspout brackets





Plastic hanger for drainpipe that runs across surface of roof											
Standard	Product number Color No. of										
60 (L120)	A254860	SB·W·SW·K	50								


H = Grey,
SB = Reddish Brown,
W = European White,
SW= Snow White,
K = Black

Design reference data

Standard eaves construction diagram







Drainage water quantity (for rainfall intensity of 160 mm/h)


Drainage water quantity in eaves trough

	-,		
Eaves trough drainage slope	1/1000	3/1000	5/1000
Drainage water quantity (\(\ell \) /sec.)	3.8	6.6	8.4

Drainage water quantity in downspout

Downspout	60	75	K35	VU75	VU100	
Drainage water quantity (\(\ell \) /sec.)	2.3	3.6	2.6	4.6	7.7	

Dimensional drawing




Eaves trough drainage slope Downspout	1/1000	Projected roof area	3/1000	Projected roof area	5/1000	Projected roof area
60	2.3	50.7	2.3	50.7	2.3	50.7
75	3.6	80.2	3.6	80.2	3.6	80.2
K35	2.6	58.3	2.6	58.3	2.6	58.3
VU75	4.7	83.8	4.6	104.0	4.6	104.0
V/L1100	7.7	83.8	7.7	1/7/	7.7	172.6

lacktriangle Drainage water quantity (ℓ /sec.) and projected roof area (m²) for each drop outlet

Compatible size chart (Based on rainfall intensity: 160 mm/h, drainage slope: 3/1000, interval between drop outlets: 12 m)

Gutter	combination	Projected roof area for								Projec	ted ro	of area	(m²)							
Eaves trough	Downspout pipe	each drop outlet (m²)	~ 100	200	~ 300	~ 400	~ 500	<u>6</u> 00	~ 700	~ 800	900	1000	~ 1100	~ 1200	~ 1300	1400	~ 1500	~ 1600	~ 1700	1800
	75	80.14	2	3	4	5	7	8	9	10	12	13	14	15	17	18	19	20	22	23
	90	116.66	1	2	3	4	5	6	6	7	8	9	10	11	12	12	13	14	15	16
D-type150	VU75	103.97	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
D type 100	VP75	89.37	2	3	4	5	6	7	8	9	11	12	13	14	15	16	17	18	20	21
	VU100	147.35	1	2	3	3	4	5	5	6	7	7	8	9	9	10	11	11	12	13
	VP100	147.35	1	2	3	3	4	5	5	6	7	7	8	9	9	10	11	11	12	13

Standard construction position



For Japanese tiles

For S-tiles

For colored slate (thin)

For colored slate (thick)



Checking of materials

Checking of location of drop outlets

Installation of eaves trough brackets

Installation of eaves troughs

Installation of drop outlets

Installation of downspout brackets

Installation of downspouts

Installation of leader heads

Connection to discharge pipes

Checking of finishing

Construction procedure and instructions Use genuine DENKA adhesive (600ZT) in order to prevent water leakage.

1. Determining location of drop outlets

The number of drop outlets is determined using the calculation for drainage water quantity.

However, taking into account the balance of the drainage water, it is ideal to provide at least 1 drop outlet on each eave.



(Funnel/drain)

Location of funnel or drain


2. Selection of eaves trough bracket

Select the eaves trough bracket according to the gradient of the fascia board, the overhang length of the eaves, and the

Four types for gradients of 0, 4/10, 5/10, 6/10.



●Inner hanger, fascia mount (slide type) Slide width = 20~50 mm



Nails for standard use (4) φ 4 .3 φ 2 .4 X 4 5 Nail/screw hole (4) Screw nail Tapping screw ϕ 4 0 X 3 5

Anchor hole (2) Anchor bolt φ6.0 X 4 5 Tapping screw φ5.0 X 3 5


Hidden hanger, roof mount

Selection of tapping screw



Caution

If using tapping screws (ϕ 4), secure the plate using the four nail/screw holes. If using anchor bolts/tapping screws (ϕ 5), use the two anchor bolt holes




*Be sure to use genuine DENKA products.


Slide width=75mm


3. Installation of brackets


- ■Install brackets on both sides of the eaves. (Gradient of 1/1000 or more)
- Stretch a leveling string along the brackets on both sides.
- ●The distance between brackets in normal regions is 600 mm or less. Install brackets at intervals of 450 mm or less in snowfall regions. In snowfall regions, install snow brackets on the roof.
- ●Installation of brackets close to components is shown in the diagrams below.



Expansion funnel









4. Cutting eaves trough


- Use a hacksaw to cut the eaves trough at a right angle.
- Remove all burrs from the cut surface.
- Deformities or burrs on the cut surface may cause gaps when the socket, etc. is installed. Therefore, always rectify deformities and burrs carefully. (Prevention of water leakage)






5. Installation onto eaves trough brackets

- Hook the eaves trough's hidden hanger lip securely onto the edge of the brackets. Then, push the base of the eaves trough up and fit the rear mounting ear.
- Check that all of the brackets are fitted into the eaves trough.








6. Installation of socket

*Use genuine DENKA adhesive (600ZT) in order to prevent water leakage.


- Apply rows of adhesive evenly around the entire circumference of the inside of the socket. Apply up to below the mounting ears ensuring that there are no gaps, particularly at the corners.
- ●Hook the socket onto the eaves trough's rear mounting ear and fit it onto the front mounting ear by rotating it forwards.









- Slide the socket all the way on.
- Set the other eaves trough and insert it all the way on.








7. Construction of snap socket










Apply rows of adhesive evenly around the entire circumference of the inside of the socket. Apply up to below the mounting ears ensuring that there are no gaps, particularly at the corners.

Matching the center of the socket to the connection point in the eaves troughs, hook it onto the eaves trough's rear mounting ear and fit it onto the eaves trough's front mounting ear by rotating it forwards.



















Insert the rear side of the inner cover into the locking groove on the rear side of the eaves trough, and fit it so that it conforms with the eaves trough.









8. Installation of expansion socket

*Use genuine DENKA adhesive (600ZT) in order to prevent water leakage.


Product description

no gaps.

The product consists of a cover, a slider, and a temporary fixing pin.


In the case of drain chutes, always use an expansion


x 2 eaves troughs).



9. Application of adhesive


Apply rows of adhesive around the entire circumference of the eaves trough insertion section of the expansion socket (slider, cover), ensuring that there are no gaps.






10. Fitting of expansion socket to eaves trough

Install the expansion socket by snapping it onto the rear side and front side of the eaves trough. Push the eaves trough all the way into the eaves trough insertion section.




The efficiency of the expansion socket cannot be maximized unless the eaves trough is connected in the correct position. Therefore, carry out the connection work without removing the temporary fixing pin. (Be sure to remove the pin after construction).



11. Removal of temporary fixing pin


The temporary fixing pin is easily removed by picking its inside surface with the tip of one's finger and rotating it upwards.




12. Installation of bend


*Use genuine DENKA adhesive (600ZT) in order to prevent water leakage.


Apply a row of adhesive evenly around the entire circumference of the insertion section of the bend, ensuring that there are no gaps.






Hook the bend onto the eaves trough's rear mounting ear, and fit it onto the eaves trough's front mounting ear by rotating it forwards.






Install the eaves trough on the other side in the same way.



13. Installation of end cap (left/right specific)


*Use genuine DENKA adhesive (600ZT) in order to prevent water leakage.

- Apply a row of adhesive evenly around the entire circumference of the insertion section of the end cap, ensuring that there are no gaps.
- Insert the end cap all the way onto the eaves trough.











14. Installation of expansion funnel


- Drop outlets
- ©Ensure that the distance between two funnels on the same level is 24 m or less.
- Olf there is a bend, ensure that the distance from the bend is 12 m or less.
- ©For gabled roofs, ensure that the edges of funnels are at 12 m or less.






Adjust the space between the two eaves troughs on the basis of 80 mm in the summer and 130 mm in the winter.


80 (summer) ~ 130 (winter) mm space between eaves troughs




Hook the expansion funnel onto the eaves troughs' rear mounting ears, and rotate it forwards to fit it onto the eaves troughs' front mounting ears with a "click".
 *Do not glue the expansion funnel to the eaves troughs.



In accordance with the construction season (summer, winter), set the eaves troughs to the indicator marks on the front top surface of the expansion funnel.





Quality/Properties

General properties of Toyo gutter

Physical properties	Specific gravity	_	1.45~1.52	Equivalent to 1/5 that of galvanized sheet iron and 1/2 that of aluminum, Toyo gutter is light and easy to construct
	Tensile strength	N/cm ²	3922.7 and above	Has the strength required of gutters
Mechanical properties	Falling ball impact	cm	120 and above	The higher the value, the more resistant the material is to breaking when a weight is dropped on it (1 kg weight)
	Modulus of elasticity	10 ⁴ N/cm ²	24.52~34.32	More elastic than metal
Thermal	Linear expansion coefficient	10-5/℃	6.0~0.29	The amount of expansion/ contraction when 1 mm of gutter undergoes a temperature change of 1°C
properties	Vicat softening temperature	°C	82~90	Standard for estimating the heat-resistant strength

Impact resistance

Rigid PVC resin has sufficient impact strength to withstand being struck by items during typhoons, etc.

[Impact resistance test]

An eaves trough was left inside a 20°C thermostatic chamber for at least 1 hour and then a 1 kg weight was dropped on it from a height of 1.2 m. The eaves trough was inspected for damage.

Eaves trough	Result
D-type 150	No damage



Has sufficient load resistance to withstand accumulation of grit in the eaves trough.

[Load on eaves trough and amount of deflection]

Туре		Effective cross-sectional drainage area (cm²)		Load (kg) when bracket interval 600 mm	Amount of deflection (mm)
D type 1	-type 150 151.9		Full of water	9.1	3.3
D-type i	50	151.9	Full of grit	12.5	4.54



The amount of expansion/contraction due to temperature difference in rigid PVC resin is large compared to metals; however, the use of expansion components (expansion, expansion sockets) means that this is not a problem in practical terms.

[Amount of expansion/contraction in gutter]

Linear expansion coefficient	Temperature difference (°C)	Amount of expansion/contraction (mm) per 10 m of eaves trough
6×10 ⁻⁵ /°C	30	18.0
	40	24.0
	50	30.0
	60	36.0


[Clash-Berg temperature of gutter]

PVC gutters have sufficient heat resistance for use, and can be used with confidence.

	Test item	Test method	Туре	Temperature (°C)	
	Vicat softening temperature	1kg load according to JIS K 7206	Eaves trough	97	
			Downspout	90	
			Part	82	



Impact resistance



Load resistance



Weather resistance

Tensile strength of bonded parts

The adhesive has sufficient strength and, in particular, the initial adhesive strength is very fast, so it can be used with confidence.

[Time-dependent tensile strength]

Unit: N/cm²

	• •	
Type of adhesive	After 3 hours	After 24 hours
600ZT	199	324
100P	195	298

Tensile shear strength was measured according to JIS K 6850.

* In order that the adhesive maintains the stated strengths, use

Weather resistance

The properties of rigid PVC resin suffer little deterioration during extended periods of use outdoors, so Toyo gutters can be used with confidence.

[Outdoor exposure test]

The product was left outside for 3 years at an angle of 45° to the south, after which the tensile strength was measured.

		Before exposure	1 year	2 years	3 years
Tens	sile strength (N/cm²)	5490	5520	5560	5620

[&]quot;genuine Toyo gutter adhesive".

DENKI KAGAKU KOGYO KABUSHIKI KAISHA Housing & Environmental Materials Dept.

Head Office : Nihonbashi Mitsui Tower, 2-1-1 Nihonbashi-Muromachi, Chuo-ku,

Tokyo 103-8338

Osaka Branch Office : Shin-Hankyu Building, 1-12-39 Umeda, Kita-ku, Osaka 530-0001

TEL: +81-6-6342-5669 FAX: +81-6-6342-5795

Nagoya Branch Office : No.3 Horiuchi Building, 4-6-23 Meieki, Nakamura-ku, Nagoya

450-0002 TEL: +81-52-561-1570 FAX: +81-52-571-7843

Fukuoka Branch Office: Fukuoka Gion Daiichi Seimei Building, 5-35 Reisen-machi,

Hakata-ku, Fukuoka 812-0039

TEL: +81-92-263-0836 FAX: +81-92-263-0845

Sapporo Branch Office: NBF Sapporo Minami Nijo Building, 2-18-1 Minami Nijo Nishi,

Chuo-ku, Sapporo 060-0062

TEL: +81-11-205-6868 FAX: +81-11-205-6978

Tohoku Branch Office : Sendai Shinwa Building, 1-10-3 Hon-cho, Aoba-ku, Sendai

980-0014

TEL: +81-22-223-92121 FAX: +81-22-713-6780

North Kanto Sales Office : Lumiere Ageo, 1-16-13 Atago, Ageo, Saitama Prefecture 362-0034

TEL: +81-48-775-3530 FAX: +81-48-774-8003

Hiroshima Sales Office: Ehime Building Hiroshima, 2-10 Mikawa-cho, Naka-ku, Hiroshima

730-0029

TEL: +81-82-249-7392 FAX: +81-82-504-6543

Shikoku Sales Office : Kagawa Tenjinmae Building, 10-12 Tenjinmae, Takamatsu 760-0018

TEL: +81-87-833-6503 FAX: +81-87-837-4011

URL http://www.denka.co.jp/eng/top.htm

Please note that product specifications, packaging specifications, and colors are subject to change without notice. Due to printing, color shades may differ from the actual product.